

WHEN TO CLEAR

OVER YOUR BASECOAT

The recoat window, one slide per rule



@thespraysource

BASE DRY TO THE TOUCH?

WAIT 30 MINUTES

Let the last basecoat flash fully before clear



@thespraysource

CLEAR WITHIN 1 HOUR

OF THE LAST COAT DRYING

That is the window for spray-can basecoat



@thespraysource

PAST 8 HOURS?

SCUFF + ONE MORE BASECOAT

Then clear within the hour



@thespraysource

ACTIVATE THE 2K CAN

ONLY WHEN READY TO SPRAY

24 hour pot life once the button is pressed



@thespraysource

2 TO 4 WET COATS

RECOAT AT FINGERPRINT

About 10 minutes between coats. Check the masking



@thespraysource

UNMASK AT 30 MINUTES

HANDLE AT 8 HOURS

Polish or recoat after 12 hours



@thespraysource

SPRAY GUN BASECOAT?

8+ HOURS: SAND 600 TO 800

Then 2 full coats of clear, 8 to 10 minutes flash



@thespraysource

READ THE FULL GUIDE

THESPRAYSOURCE.COM

/pages/spray-cans



@thespraysource