

SPRAY GUN SETUP

TIP, PRESSURE, DISTANCE

The numbers for every product



@thespraysource

BASECOAT AND METALLICS

1.3MM TIP, 25 TO 30 PSI

Metallic base: 25 to 28 PSI



CLEARCOAT

1.4 TO 1.5MM TIP, 30 TO 35 PSI

Keep separate tips for base and clear



@thespraysource

PRIMER

1.5 TO 1.7MM TIP, 35 TO 40 PSI

Heavy primer and filler: 1.7 to 2.0mm




@thespraysource

CANDY AND SPECIALTY

20 TO 25 PSI

Too high: thin and poor coverage. Too low: thick and chunky



@thespraysource

MEASURE AT THE CAP

NOT THE COMPRESSOR

Cap pressure is 5 to 10 PSI lower



6 TO 8 INCHES AWAY

PERPENDICULAR TO THE PANEL

Keep the gun moving at a steady speed




@thespraysource

TEST ON CARDBOARD

ROUND, EVEN, 4 TO 6 INCHES

Too wide: less pressure. Too tight: more pressure



@thespraysource

FLUID CONTROL

1 TO 2 DROPS PER SECOND

Streaky? Clean the nozzle and needle



READ THE FULL GUIDE

THESPRAYSOURCE.COM

</pages/spray-gun-setup>



@thespraysource