WET SAND AND POLISH

THE MIRROR FINISH STEPS

1500, 2000, 3000, compound, polish



@thespraysource

WAIT 12 HOURS AT 68F

48 IN A COLD GARAGE

HS Glamour and Euro clear. Rapid clear: 2.5 to 3 hours



@thespraysource

1500 GRIT, KEEP IT WET

STRAIGHT STROKES, 50% OVERLAP

Done when the whole panel is flat matte with no shiny spots

@thespraysource

GO EASY ON EDGES

CLEAR IS THINNEST THERE

See color on the paper? Stop. That spot needs reclear

@thespraysource

2000 GRIT

90 DEGREES TO THE LAST PASS

Done when the 1500 scratches become a finer haze

@thespraysource

3000 GRIT

OPTIONAL BUT RECOMMENDED

Faster compounding, fewer swirls

@thespraysource

COMPOUND

DA POLISHER, SMALL SECTIONS

About 2 by 2 feet. Keep it moving

@thespraysource

FINISHING POLISH

FINISHING PAD, THEN INSPECT

Removes micro swirls. Wipe with microfiber

@thespraysource

NEVER SAND DRY

NEVER SKIP GRITS

Keep pads clean

@thespraysource

READ THE FULL GUIDE

THESPRAYSOURCE.COM

/pages/wet-sanding-polishing

@thespraysource