PAINT YOUR WHEELS

WITH A SPRAY CAN KIT

Start to finish, one slide per step



@thespraysource

WASH OFF THE BRAKE DUST

WHEEL CLEANER + MITT

Dry, then isopropyl alcohol. Keep it off the tires



@thespraysource

SCUFF THE WHOLE WHEEL

GRAY SCUFF PAD UNTIL FLAT

No shiny spots. Rinse, dry with rag and compressed air



@thespraysource

FIT THE TIRE MASKS

NO TAPE BRIDGING

Final wipe with microfiber and remover



@thespraysource

1K EPOXY: 1 LIGHT, 5 MIN, 1 WET

THEN WAIT 1 HOUR

Dry to the touch, then wait 1 hour. Shake 45 to 60 seconds.



@thespraysource

BASECOAT: 2 TO 4 COATS

10 MINUTES OR UNTIL MATTE

Metallics: one light control coat last



@thespraysource

CLEAR WHEN DRY

15 MIN IN A BOOTH

Dry to the touch: else 30 to 60 min at 70F or warmer



@thespraysource

2K CLEAR: 2 TO 3 WET COATS

RECOAT AT FINGERPRINT

Pull the ring and bar first. Wear a respirator, gloves and goggles



@thespraysource

UNMASK AT 30 MINUTES

MOUNT AFTER 8 HOURS

12 hours before polishing. Flip cans and clear the nozzle



@thespraysource

READ THE FULL GUIDE

THESPRAYSOURCE.COM

/pages/wheel-paint-kit-guide



@thespraysource